



# DYMO LabelPOINT 100 Cutting Blade Replacement

Replace a dull, broken, or jammed cutting blade.

Written By: Dustin Holifer





## TOOLS:


- [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Rear Panel



- Slide the panel release button.
- Lift the panel.


## Step 2 — Remove Label Tape Cassette



- Firmly press the cartridge release button with your finger.
  - You may need to hold the cassette and/or entire device still while pressing the button.
- Lift the label tape cassette out of the device.




### Step 3 — Blade Disassembly



- Use Phillips #00 Screwdriver to disengage cutter from device
- Remove cutter

### Step 4 — Remove Blade



- Use Phillips #00 screw to unscrew blade from blade cutter
- ⚠ Carefully remove blade. The blade is sharp and can be dangerous if not handled properly.
- Replace blade

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 06:52:51 PM.